

# Wireless Doorbell Button



## OVERVIEW

The Axxess Wireless Doorbell Button is beautifully designed to welcome guests at your door. A press of the button wirelessly activates our chime relay or other configured devices.

Installation is simple. With a long lasting lithium battery there is no wiring necessary and its surface mount design means you have a choice between using two screws or the peel and stick adhesive strips.

Since the Axxess Doorbell Button communicates with the controller, doorbell rings can be turned off for pre-programmed events such as "baby asleep." Fully compatible with Control4.

Two external contacts enable detection of whether the door is closed and whether the deadbolt is engaged



# Wireless Doorbell Button

DB-C4ZB-11

## USES

- Chime activation
- Multi-purpose button

## WIRELESS

ZigBee PRO Compatible  
(802.15.4)  
Control4 Driver Downloadable

## COMPLIANCE/APPROVALS

FCC Part 15 | CE

## TEMPERATURE SENSOR

Accurate to +/- 1°C Operating  
range of -40°C to 70°C

## BUTTON FUNCTION

Button press sends wireless  
ZigBee message to controller or  
directly to Doorbell Relay

## POWER SPECS

3.6 V AAA cell (ER14505), -55C to  
85C range in temperature  
Low battery notification

## EXTERNAL CONTACTS

Magnetic or wire leads optional

## COLOR

Black | White

## DIMENSIONS

W 1.1875" x H 2.75" x D 0.5"  
W 3.02cm x H 6.99cm x D 1.27cm

## MOUNTING

Double sided adhesive or 2 screws

## DRIVERS

Download from  
[www.axxind.com/dealers/drivers](http://www.axxind.com/dealers/drivers)

## HOW TO ORDER

[axxind.com/dealers](http://axxind.com/dealers)

## WHAT'S IN THE BOX

